

GT USA ELOGS ELD

ELD System

GT USA ELOGS ELD solution ensures FMCSA compliance and delivers superior safety and productivity for any fleet.

gtelogs.com

Contact the support team at info@gtelogs.com

Main Features

ELD Compliance and much more

Automatic HOS

Automatic hours of service calculation and violation alerts.

Automatic recording of driving time, miles and locations.



Compliance Monitoring

Monitor your drivers' hours of service logs and DVIRs.

Receive alerts to prevent violations.

DOT Inspection Mode

Simply show logs on your phone or tablet.

No printer needed.



Fleet Tracking

Track your vehicles in real time and view their location history.

Multiple HOS Rules

Compliant with multiple HOS rules including

Property/Passenger 60-hour/7-day & 70-hour/8-day.



IFTA reporting

Automatic IFTA state mileage reporting saves you time and money.

Electronic DVIR

Vehicle inspection reports are created and submitted in seconds.



Access Permissions

Manage permissions for fleet managers, compliance officers, drivers, accountants, brokers and customers

gtelogs.com

Contact the support team at info@gtelogs.com

ELD Components

Things You Need To Stay Compliant

Logging Device



Easy to install logging device. Simply plug ELD into a vehicle ECM port and start recording driving hours and miles automatically.

Logbook App



User Friendly app for managing hours of service logs. It connects to ELD via bluetooth and displays recorded driving time to a driver.

Tablet/Smartphone



GT USA ELOGS ELD & App work great with most Android 3G/4G tablets and smartphones. Use your own or purchase devices and data plans from us.

gtelogs.com

Contact the support team at info@gtelogs.com

Install & Connect ELD

GT USA ELOGS ELDs are installed within minutes



✓ Locate ECM (diagnostic) port

Locate ECM (diagnostic) port inside of your vehicle. Look for 9-pin or 6-pin circular ports in heavy duty vehicles. Look for OBDII port in light/medium duty vehicles.

✓ Install ELD

Simply plug the provided cable into a vehicle ECM (diagnostic) and attach the other end to the ELD device. The dual fastener is provided for dash mounting.

✓ Log into GT USA ELOGS Logbook App

Log in to HOS 247 Logbook App on your tablet/smartphone with a username and password created during a sign up process or provided by a fleet manager.

✓ Connect ELD

Select a vehicle from a list of available vehicles and your device will attempt to connect to ELD via Bluetooth. Green Bluetooth indicator at the top right corner means you are ready to start using ELD.

gtelogs.com

Contact the support team at info@gtelogs.com

Driving with ELD



- ✓ Once ELD connected, your driving time will be captured automatically.
- ✓ Once your vehicle is moving at 5mph or more, your duty status is switched to Driving.
- ✗ Your logs and others features are not available while in Driving mode due to safety reasons.
- ✓ Once your vehicle is stopped, you may change your duty status by tapping on the status circle. The app will remind you to make a selection in 5 minutes. If no selection is made, your duty status will be switched to On Duty.



Hours

Available driving hours, required breaks, on-duty limits and required off-duty time are calculated automatically




Warnings

Visual notifications and sound warnings help you to avoid hours of service violations and stay compliant

gtelogs.com

Contact the support team at info@gtelogs.com



Duty Status

Set duty status with just two-clicks. Status is updated automatically when driving starts or stops, Easy-to-use interface allows drivers to spend less time doing paperwork and more time driving. **GT USA ELOGS** ELD simplifies training and prevents log errors.



Current Status

Current duty status is always displayed on Status page inside of status circle along with available or reset hours.



Change Status

Tap the status circle, select your current status, add a note if necessary (i.e. pre-trip inspection) and press "Update" button.



Personal/Yard

Personal Use Off-duty and Yard Move On-Duty statuses must be configured and allowed by a fleet manager.

gtelogs.com

Contact the support team at info@gtelogs.com

Logs

Managing logs has never been easier



Today's Log

Tap on TODAY's log to view & manage your current log.




Logs History

View past logs & violations if any. Tap on a log you would like to view or edit.



Graph Grid

Similar to paper logs, view your hours or service on the graph grid.



Statuses/Events

Tap on a specific status in the events section to view location and notes.



Edit/Insert Status

Press on "Pencil" to edit or "+" to insert a past duty status.



Certify Log

Tap "Certify" and sign your log when your shift ends.

gtelogs.com

Contact the support team at info@gtelogs.com

DVIRs

Paper-free DVIRs save time for drivers



Add DVIR

Tap "+" to add pre-trip or post-trip inspection report




Defects

Select defects (if any) from the list and sign DVIR



Correct Defects

Notify mechanic if defects need to be corrected



Review last DVIR

Tap on DVIR to review and to confirm the issues have been resolved



DVIRs History

Review past DVIRs to prevent compliance errors



Edit DVIR


Tap "..." button to edit DVIR and to fix any errors

gtelogs.com

Contact the support team at info@gtelogs.com

Easy to Use & to Navigate

The driver(user)-friendly ELD interface



**Easy-to-Navigate
& Simple Menu**



**Tap "Start Inspection"
for DOT Mode**



**View HOS Rules and
Exceptions**

gtelogs.com

Contact the support team at info@gtelogs.com

Compliance Dashboard

Make sure your drivers stay compliant and productive



Current Status

View current statuses and locations of your drivers. Click on a driver to see details.



Real-Time Hours

View real-time hours to avoid violations and regulatory fines



Violations

Monitor violations in real time and mitigate compliance risks

The screenshot shows the ELD (Electronic Logging Device) dashboard interface. The top navigation bar is purple with the 'ELD' logo and a back arrow. Below the navigation bar, there's a sidebar menu with options: Drivers, Vehicles, Logs, DVIRs, IFTA, and Manage. The main content area displays a 'Drivers' table with columns for NAME, STATUS, LOCATION, VEHICLE, BRAND, MAKE, YEAR, CYCLE, VIOLATIONS, and LAST ACTIVITY. The table lists several drivers with their current status (e.g., 'Driving', 'Off Duty') and last activity dates.

NAME	STATUS	LOCATION	VEHICLE	BRAND	MAKE	YEAR	CYCLE	VIOLATIONS	LAST ACTIVITY
Mark Anthony	Driving	75 W. Hill of Falls, AL	Truck 18 FT300	ISUZU	2018	2018	0024		2024-01-24
Vincent Jay	Driving	76 E. Hill of Hartsfield, FL	Truck 1 FT300	ISUZU	2018	2018	0011		Jan 24
Sammy	Off Duty	Minneapolis, MN	Truck 20 FT300	ISUZU	2018	2018	0026		Jan 24
Gregg Howard	Driving	66 N. Hill of Hill, Pensacola, FL	Truck 20 FT300	ISUZU	2018	2018	0026		Jan 23
Stephen Tyler	Driving	40 W. Hill of Hill, Houston, TX	Truck 20 FT300	ISUZU	2018	2018	0026		Jan 23
John Deere	Off Duty	173 W. Hill of Andover, MN	Truck 20 FT300	ISUZU	2018	2018	0026		Jan 23

gtelogs.com

Contact the support team at info@gtelogs.com

Driver Details

Everything about the driver in one place

Vincent Jay Edit Refresh

0003452345 | jay@gtelogs.com | USA Priority Truck | E-Log | Last Update: JAN 21 4:30 PM EST

Hours of Service

STATUS	DATE	VEHICLE	LOCATION	BEAK	DRIVE	SHIFT	STOLE
IMMUNE	JAN 11 4:00 PM EST	Truck 23 - FT203	14.0 mi NE of Harrisburg, PA	05:12	08:12	11:03	67:12

> Recap
> More

Logs

Recent Log

DATE	HOURS DRIVE	DISTANCE	VIOLATIONS & ERRORS
11 Jan 2017	2 hours	278 mi	

Last 14 Days More

DATE	HOURS DRIVE	DISTANCE	VIOLATIONS & ERRORS
10 Jan 2017	18	327 mi	
11 Jan 2017	18	427 mi	
12 Jan 2017	18	398 mi	
13 Jan 2017	18	310 mi	
14 Jan 2017	18	321 mi	
15 Jan 2017	18	362 mi	
16 Jan 2017	18	381 mi	
17 Jan 2017	18	394 mi	



Hours of Service

View current status and real-time hours. Available and reset hours are calculated automatically



Driver Logs

View current log graph grid and last 14 logs. Click on a log to see log details. Click "More" to view historical logs.



Violations & Errors

Monitor violations and errors in real time. View past violations and mitigate compliance risks.




Details

View driver contact information, current or last known vehicle and location.

Logs

Make sure your drivers stay compliant and productive



View logs

View all current and past logs up to six months



Filter

Filter by date or driver



Violations

Monitor violations in real time

gtelogs.com

Contact the support team at info@gtelogs.com

Log Details

Log form and events

Tue Jan 24, 2017 01/24/2017

John Smith USA Property 70 Hour 18 Day ✔ Certified ✔ No Violations


Log Form

General			
Driver	Vincent Jay	Co Driver	
Driver ID	35742	Co Driver ID	
Driver License	0000034665030246741	ELD S/N	JD05774564
Driver License State	CA	ELD Manufacturer	HDS 247
Exempt Driver Status	No	Data Diagnostic Indicators	No
Unidentified Driving Records	No	ELD Malfunction Indicators	No

Vehicles & Trailers				
VEHICLE	VIN	START END ODOMETER	DISTANCE	START END ENGINE HOURS
PT920	ACH34543F38DAE	39564 - 39844	420 mi	758.2 - 765.7
TRAILERS	SHIPPING DOCS	CARRIER	MAIN OFFICE	HQ&M TERMINAL
2800	128406	USA Trucking	10821 Excelsior Blvd, Hopkins MN, 55343	10621 Excelsior Blvd, Hopkins MN, 55343

Log

Log Overview 🔄



TIME (PST)	EVENT STATUS	LOCATION	ODOMETER	ENGINE HOURS	ORIGIN	NOTES
0:00	SB	49 mi NVE Fallon, NV	30564	758.2	Driver	
10:00	Login	49 mi NVE Fallon, NV	30564	758.2	Driver	
10:00	OCND	49 mi NVE Fallon, NV	30564	758.2	Driver	
10:30	OCND	49 mi NVE Fallon, NV	30564	758.2	Auto	
12:00	Driving	3 mi E Farley, NV	30620	759.3	Auto	
12:00	Off Location	3.5 mi SW Davis, CA	30604	760.3	Auto	



Log Form

Form and manner errors are displayed automatically.



Vehicles & Trailers

View vehicle & trailer information. Check shipping document numbers.



Log Events

Check log events. Click on event to suggest an edit. Click "+" to suggest to add an event.



Log Date

Click on a calendar in the top right corner to change a date or click "<->" to switch between logs,

gtelogs.com

Contact the support team at info@gtelogs.com